

WORKSHOP PROBLEM 1e

*Spring Element with Nonlinear
Analysis Parameters
(filter using restart)*



Objectives:

- Demonstrate another use of the restart feature of a multistep analysis by keeping only the first part of the analysis as a separate result file.



Model Description:

Below is a finite element representation of a rod connected to a grounded spring via a roller. The grounded spring will be modeled using a DOF spring element. An incremental load is applied at the junction of these elements. A nonlinear analysis with the large displacements option enabled will be performed on the model.

Figure 1e.1




Table 1e.1 - Properties

Elastic Modulus:	1.0E7 psi
Length:	10.0 in
Bar Cross Sectional Area:	0.01 in²
Spring Constant (K):	1.0E3 lb/in

Table 1e.2 - Load Cases

Subcase	Load	Load Increments	Note
1	16.E3 lbs	4	Do not use line search, quasi-Newton updates or bisection, and print output at every load step.
2	24.E3 lbs	8	Use work criteria for convergence and print output at every load step.
3	29.E3 lbs	5	Request output at the end of the subcase.

Exercise Procedure:

1. Start up MSC/NASTRAN for Windows V3.0 and begin to create a new model.

Double click on the icon labeled MSC/NASTRAN for Windows V3.0.

On the *Open Model File* form, change the directory to **C:\temp**.

Open Model File:

prob1d

(Optional) For users who wish to remove the default rulers in the work plane model, please do the following:

View/Options...

● **Tools and View Style**

Category:

Workplane and Rulers

Draw Entity

Apply

Cancel

2. Restart the analysis.

File/Export/Analysis Model...

Analysis Type:

10..Nonlinear Static

OK

Change the directory to **C:\temp**.

File name:

prob1e

Write

Run Analysis

Restarts...

● **Restart Previous Analysis**

Restart Control:

OK

On the *Restart From Database* form, change the directory to **C:\temp**.

File name:

prob1c.MASTER

Open

Advanced...

Problem ID:

**Spring Element Problem,
Filter Using Restart**

OK

Under *Output Requests*, change the output to:

1..PostProcess Only

Also deselect all the boxes except the following:

Displacement

Element Force

Under *Analysis Case Requests*, enter the following to restart the analysis keeping only the first 8 increments (subcase 1 and half of subcase 2):

Type Input...

Current Line:

PARAM, LOOPID, 8

More

Current Line:

PARAM, SUBID, 4

OK

SUBCASE ID:

1

Loads =

1..load_1

Write Case...

Click **OK** when you receive the confirmation that the subcase has been written.

OK

Under *Analysis Case Requests*, enter the following:

<i>SUBCASE ID:</i>	<input type="text" value="2"/>
<input checked="" type="checkbox"/> Loads =	<input type="text" value="2..load_2"/>
<input type="button" value="Write Case..."/>	

Click **OK** when you receive the confirmation that the subcase has been written.

Under *Analysis Case Requests*, enter the following:

<i>SUBCASE ID:</i>	<input type="text" value="3"/>
<input checked="" type="checkbox"/> Loads =	<input type="text" value="3..load_3"/>
<input type="button" value="OK"/>	

Click **OK** when you receive the confirmation that the subcase has been written.

When asked if you wish to save the model, respond **Yes**.

When the MSC/NASTRAN manager is through running, MSC/NASTRAN will be restored on your screen, and the *Message Review* form will appear. To read the messages, you could select **Show Details**. Since the analysis ran smoothly, we will not bother with the details this time.

When asked if it is "OK to Begin Reading File C:\TEMP\prob1e.xdb," respond **Yes**.

3. List the results of the analysis.

To list the results, select the following:

List/Output/Query...

<i>Output Set:</i>	<input type="text" value="42..Case 4 Step 1.000000"/>
<i>Category:</i>	<input type="text" value="1..Displacement"/>
<i>Entity:</i>	<input type="radio"/> Node
<i>ID:</i>	<input type="text" value="1"/>
<input type="button" value="OK"/>	

NOTE: You may want to expand the message box in order to view the results. To do this, double click on the message box. Adjust the size of the box to your preference by dragging the top border downward.

Answer the following questions using similar procedure. The answers are listed at the end of the exercise.

For each load set, what is the maximum T1 displacement at the guided end, **Node 1**?

Step 1 Max T1 @ Node 1 = _____

Step 1.5 Max T1 @ Node 1 = _____

4. Display the deformed plot and the fringe plot on the screen.

View/Select...

<i>Deformed Style:</i>	<input checked="" type="radio"/> Deform
<i>Contour Style:</i>	<input checked="" type="radio"/> Contour

Deformed and Contour Data...

<i>Data Selection/Category:</i>	<input type="text" value="0..Any Output"/>
<i>Output Set:</i>	<input type="text" value="(Sequentially select the result cases.)"/>
<i>Output Vectors/Deformation:</i>	<input type="text" value="2..T1 Translation"/>
<i>Output Vectors/Contour:</i>	<input type="text" value="3036..Rod Axial Force"/>
<input type="button" value="OK"/>	
<input type="button" value="OK"/>	

As you look at each result case, you will notice that the change in deflection lessens as more of the loading force is axially distributed. This is the benefit of running a nonlinear geometric analysis, which accounts for large displacements that change the distribution of the force along the beam.

This concludes the exercise.



7.06266	<i>Step 1.5 Disp X:</i>
6.30076	<i>Step 1 Disp X:</i>