

WORKSHOP PROBLEM 2b

Geometric Nonlinear Analysis of a Cantilever Beam




Objectives:

- Demonstrate the use of geometric nonlinear analysis.
- Observe the behavior of the cantilever beam under four increasing load magnitudes.
- Look at the displacement along the length of the beam for each subcase.
- Generate a Displacement versus Subcase plot from the result.



Model Description:

Below in Figure 2b.1 is a finite element representation of a cantilever beam. An incremental load will be applied at the tip of the beam. Through a nonlinear analysis of the beam, the displacement at the tip will be determined under different loading conditions.

Figure 2b.1**Table 2b.1 - Properties**

Elastic Modulus:	1.0E7 psi
Poisson's Ratio:	0.3
Length:	10.0 in
Bar Cross Sectional Area:	1.0 in²
Moments of Inertia, I₁₁:	1.0E-2 in⁴
Moments of Inertia, I₂₂:	1.0E-2 in⁴

Table 2b.2 - Load Cases

Subcase	Load (P)
1	2000 lbs
2	4000 lbs
3	6000 lbs
4	8000 lbs

Exercise Procedure:

1. Start up MSC/NASTRAN for Windows V3.0 and begin to create a new model.

Double click on the icon labeled MSC/NASTRAN for Windows V3.0.

On the *Open Model File* form, change the directory to **C:\temp**.

Open Model File:

prob2a

(Optional) For users who wish to remove the default rulers in the work plane model, please do the following:

View/Options...

Tools and View Style

Category:

Workplane and Rulers

Draw Entity

Apply

Cancel

2. Activate load set.

Model/Load/Set...

Title:

1..load_1

OK

3. Define the nonlinear analysis parameters for the load case.

Model/Load/Nonlinear Analysis...

Solution Type:

Static

Defaults...

OK

NOTE: It is not necessary to reapply the load at the tip since it has already been defined in the previous exercise using the Static default settings.

4. Repeat **Steps 2 & 3** to activate and define the nonlinear parameters for each subcase.
5. Submit the job for analysis.

File/Export/Analysis Model...*Analysis Type:***10..Nonlinear Static****OK**Change the directory to **C:\temp**.*File name:***prob2b****Write** **Run Analysis****Advanced...***Problem ID:***Nonlinear Analysis of a
Cantilever Beam****OK**Under *Output Requests*, change the output to:**1..PostProcess Only**

Also deselect all the boxes except the following:

 DisplacementUnder *Analysis Case Requests*, enter the following:*SUBCASE ID:***1** **Loads =****1..load_1****Write Case...**Click **OK** when you receive the confirmation that the subcase has been written.**OK**

Under *Analysis Case Requests*, enter the following:

SUBCASE ID:

Loads =

Click **OK** when you receive the confirmation that the subcase has been written.

Under *Analysis Case Requests*, enter the following:

SUBCASE ID:

Loads =

Click **OK** when you receive the confirmation that the subcase has been written.

Under *Analysis Case Requests*, enter the following:

SUBCASE ID:

Loads =

Click **OK** when you receive the confirmation that the subcase has been written.

When asked if you wish to save the model, respond **Yes**.

When the MSC/NASTRAN manager is through running, MSC/NASTRAN will be restored on your screen, and the *Message Review* form will appear. To read the messages, you could select **Show Details**. Since the analysis ran smoothly, we will not bother with the details this time.

Continue

When asked if it is “OK to Begin Reading File C:\TEMP\prob2b.xdb,” respond **Yes**.

Yes

6. List the results of the analysis.

To list the results, select the following:

List/Output/Standard...

Select All

OK

To look at the displacement in the T2 direction of a node,

Sort Field:

3..T2 Translation

Options:

Details Only

Format ID:

0..NASTRAN Displacement

OK

Select **Node 11**.

OK

NOTE: You may want to expand the message box in order to view the results. To do this, double click on the message box. Adjust the size of the box to your preference by dragging the top border downward.

Answer the following questions using the results. The answers are listed at the end of the exercise.

What is the T2 displacement **Node 11** for each subcase?

T2 disp @ Node 11, Subcase 1 (Set 5) = _____

T2 disp @ Node 11, Subcase 2 (Set 6) = _____

T2 disp @ Node 11, Subcase 3 (Set 7) = _____

T2 disp @ Node 11, Subcase 4 (Set 8) = _____

7. Display the deformed plot on the screen.

View/Select...

Deformed Style:

Deform

Deformed and Contour Data...

Data Selection/Category:

1..Displacement

Output Set:

5..Case 1 Step 1.000000

Output Vectors/Deformation:


3..T2 Translation

OK

OK

The XY view should appear as follows (with 0.6 magnification):

Figure 2b.2



8. Create an XY plot of Displacement versus Load Cases.

View/Select...

XY Style:

XY vs Set

XY Data...

Data Selection/Category:

1..Displacement

Output Set:

5..Case 1 Step 1.000000

Output Vectors:

3..T2 Translation

Output Location/Node:

11

Show Output Sets:

From:

5

To:

8

OK

OK

Reformat the plot.

View/Options...

Category:

PostProcessing

Options:

XY X Range/Grid

Axis Range:

2..Max Min

Minimum:

5


Maximum:

8

OK

The XY plot should appear as follows:

Figure 2b.3



Notice that there is no longer a linear relationship between the displacement and the load case (linearly increasing load).

9. Create an XY plot of the Displacement along the length of the beam for all four subcases.

View/Options...

Category:

PostProcessing

Options:

Axis Range:

Minimum:

Maximum:

View/Select...

XY Style:

XY vs Position

Data Selection/Category:

Curve:

1

Output Set:

*Output Vectors:***3..T2 Translation**

Create the displacement curve for subcase 2.

Curve:

● 2

*Data Selection/Category:***1..Displacement***Output Set:***6..Case 2 Step 2.000000***Output Vectors:***3..T2 Translation**

Create the displacement curve for subcase 3.

Curve:

● 3

*Data Selection/Category:***1..Displacement***Output Set:***7..Case 3 Step 3.000000***Output Vectors:***3..T2 Translation**

Create the displacement curve for subcase 4.

Curve:

● 4

*Data Selection/Category:***1..Displacement***Output Set:***8..Case 4 Step 4.000000***Output Vectors:***3..T2 Translation****OK****OK**

You should now see four curves on the XY plot viewport. Each curve represents a unique load case.

<i>Disp Y, Subcase 1:</i>	4.93820
<i>Disp Y, Subcase 2:</i>	6.70850
<i>Disp Y, Subcase 3:</i>	7.45842
<i>Disp Y, Subcase 4:</i>	7.86575

This concludes the exercise.





Figure 2b.4

WORKSHOP PROBLEM 2b

Geometric Nonlinear Analysis of a Cantilever Beam




Objectives:

- Demonstrate the use of geometric nonlinear analysis.
- Observe the behavior of the cantilever beam under four increasing load magnitudes.
- Look at the displacement along the length of the beam for each subcase.
- Generate a Displacement versus Subcase plot from the result.



Model Description:

Below in Figure 2b.1 is a finite element representation of a cantilever beam. An incremental load will be applied at the tip of the beam. Through a nonlinear analysis of the beam, the displacement at the tip will be determined under different loading conditions.

Figure 2b.1**Table 2b.1 - Properties**

Elastic Modulus:	1.0E7 psi
Poisson's Ratio:	0.3
Length:	10.0 in
Bar Cross Sectional Area:	1.0 in²
Moments of Inertia, I₁₁:	1.0E-2 in⁴
Moments of Inertia, I₂₂:	1.0E-2 in⁴

Table 2b.2 - Load Cases

Subcase	Load (P)
1	2000 lbs
2	4000 lbs
3	6000 lbs
4	8000 lbs

Exercise Procedure:

1. Start up MSC/NASTRAN for Windows V3.0 and begin to create a new model.

Double click on the icon labeled MSC/NASTRAN for Windows V3.0.

On the *Open Model File* form, change the directory to **C:\temp**.

Open Model File:

prob2a

(Optional) For users who wish to remove the default rulers in the work plane model, please do the following:

View/Options...

Tools and View Style

Category:

Workplane and Rulers

Draw Entity

Apply

Cancel

2. Activate load set.

Model/Load/Set...

Title:

1..load_1

OK

3. Define the nonlinear analysis parameters for the load case.

Model/Load/Nonlinear Analysis...

Solution Type:

Static

Defaults...

OK

NOTE: It is not necessary to reapply the load at the tip since it has already been defined in the previous exercise using the Static default settings.

4. Repeat **Steps 2 & 3** to activate and define the nonlinear parameters for each subcase.
5. Submit the job for analysis.

File/Export/Analysis Model...*Analysis Type:***10..Nonlinear Static****OK**Change the directory to **C:\temp**.*File name:***prob2b****Write** **Run Analysis****Advanced...***Problem ID:***Nonlinear Analysis of a
Cantilever Beam****OK**Under *Output Requests*, change the output to:**1..PostProcess Only**

Also deselect all the boxes except the following:

 DisplacementUnder *Analysis Case Requests*, enter the following:*SUBCASE ID:***1** **Loads =****1..load_1****Write Case...**Click **OK** when you receive the confirmation that the subcase has been written.**OK**

Under *Analysis Case Requests*, enter the following:

SUBCASE ID:

Loads =

Click **OK** when you receive the confirmation that the subcase has been written.

Under *Analysis Case Requests*, enter the following:

SUBCASE ID:

Loads =

Click **OK** when you receive the confirmation that the subcase has been written.

Under *Analysis Case Requests*, enter the following:

SUBCASE ID:

Loads =

Click **OK** when you receive the confirmation that the subcase has been written.

When asked if you wish to save the model, respond **Yes**.

When the MSC/NASTRAN manager is through running, MSC/NASTRAN will be restored on your screen, and the *Message Review* form will appear. To read the messages, you could select **Show Details**. Since the analysis ran smoothly, we will not bother with the details this time.

Continue

When asked if it is “OK to Begin Reading File C:\TEMP\prob2b.xdb,” respond **Yes**.

Yes

6. List the results of the analysis.

To list the results, select the following:

List/Output/Standard...

Select All

OK

To look at the displacement in the T2 direction of a node,

Sort Field:

3..T2 Translation

Options:

Details Only

Format ID:

0..NASTRAN Displacement

OK

Select **Node 11**.

OK

NOTE: You may want to expand the message box in order to view the results. To do this, double click on the message box. Adjust the size of the box to your preference by dragging the top border downward.

Answer the following questions using the results. The answers are listed at the end of the exercise.

What is the T2 displacement **Node 11** for each subcase?

T2 disp @ Node 11, Subcase 1 (Set 5) = _____

T2 disp @ Node 11, Subcase 2 (Set 6) = _____

T2 disp @ Node 11, Subcase 3 (Set 7) = _____

T2 disp @ Node 11, Subcase 4 (Set 8) = _____

7. Display the deformed plot on the screen.

View/Select...

Deformed Style:

Deform

Deformed and Contour Data...

Data Selection/Category:

1..Displacement

Output Set:

5..Case 1 Step 1.000000

Output Vectors/Deformation:


3..T2 Translation

OK

OK

The XY view should appear as follows (with 0.6 magnification):

Figure 2b.2



8. Create an XY plot of Displacement versus Load Cases.

View/Select...

XY Style:

XY vs Set

XY Data...

Data Selection/Category:

1..Displacement

Output Set:

5..Case 1 Step 1.000000

Output Vectors:

3..T2 Translation

Output Location/Node:

11

Show Output Sets:

From:

5

To:

8

OK

OK

Reformat the plot.

View/Options...

Category:

PostProcessing

Options:

XY X Range/Grid

Axis Range:

2..Max Min

Minimum:

5


Maximum:

8

OK

The XY plot should appear as follows:

Figure 2b.3



Notice that there is no longer a linear relationship between the displacement and the load case (linearly increasing load).

9. Create an XY plot of the Displacement along the length of the beam for all four subcases.

View/Options...

Category:

PostProcessing

Options:

Axis Range:

Minimum:

Maximum:

View/Select...

XY Style:

XY vs Position

Data Selection/Category:

Curve:

1

Output Set:

*Output Vectors:***3..T2 Translation**

Create the displacement curve for subcase 2.

Curve:

● 2

*Data Selection/Category:***1..Displacement***Output Set:***6..Case 2 Step 2.000000***Output Vectors:***3..T2 Translation**

Create the displacement curve for subcase 3.

Curve:

● 3

*Data Selection/Category:***1..Displacement***Output Set:***7..Case 3 Step 3.000000***Output Vectors:***3..T2 Translation**

Create the displacement curve for subcase 4.

Curve:

● 4

*Data Selection/Category:***1..Displacement***Output Set:***8..Case 4 Step 4.000000***Output Vectors:***3..T2 Translation****OK****OK**

You should now see four curves on the XY plot viewport. Each curve represents a unique load case.

<i>Disp Y, Subcase 1:</i>	4.93820
<i>Disp Y, Subcase 2:</i>	6.70850
<i>Disp Y, Subcase 3:</i>	7.45842
<i>Disp Y, Subcase 4:</i>	7.86575

This concludes the exercise.




Figure 2b.4